

Operating Modes and Cooling Capabilities of the Flight ADR for the SXS Instrument on Astro-H


Peter Shirron

Key ADR team members: Mark Kimball, Michael DiPirro

Astro-H/SXS




www.nasa.gov

NASA Goddard Space Flight Center





Astro-H Soft X-ray Spectrometer

- 6x6 array of x-ray microcalorimeters cooled to 50 mK




ADR Driving Requirements

- ADR is used to cool the detectors to 50 mK
 - 0.25-0.40 μW of conducted heat (leads)
- ADR rejects heat to either:
 - Superfluid helium at $<1.3\text{ K}$
 - $<0.23\text{ mW}$ average (4 year lifetime)
 - Joule-Thomson cooler at $\sim 4.5\text{ K}$
 - $<18\text{ mW}$ peak
- Detector housing stable to 1 mK (time scales of 02 sec to 10 min)
- 90% observing efficiency




Requires 3-stage ADR

Astro-H Cryogenic System



NASA/GSFC hardware

ADR Layout





2-Stage ADR

Stage 1:

- 270 g CPA
- 2 T, 2 amp magnet

Stage 2:

- 150 g GLF
- 3 T, 2 amp magnet




Heat switches are active gas-gap

3rd Stage ADR

Stage 3:

- 150 g GLF
- 3 T, 2 amp magnet




Thermal strap
to He tank


Thermal strap
to JT

Heat switches are active gas-gap

Flight ADR, Detector and Dewar (April '14)




Astro-H Cryogenic System




ADR Operation with Helium

- 2-stage ADR operates by cascading heat from the detectors to the liquid helium



Operation in Cryogen-Free Mode


- 3rd stage transfers heat to JT cooler
- 2nd stage maintains helium tank temperature
- 1st stage cools detectors to 50 mK



Operation with Liquid Helium


- Recycling sequence

- Stage 1 and 2 are warmed to ~10% above the He bath
 - HS1 and HS2 turned ON
- Stages 1 and 2 charge to full field (2 T and 3 T)
 - HS2 is turned off
- Stage 2 cools Stage 1 (still at 2 T) to <0.8 K
 - HS1 is turned off
- Stage 1 is demagnetized to 50 mK, and Stage 2 to 0.5 K



50 mK Stage Operation

- 2-stage ADR is automatically recycled when the first stage current falls below 5 mA
 - Temperature control becomes less stable




Stage 1 Performance

- Demagnetized from 0.75 K and 2 T (0.16 J max cooling capacity)
- Hold time with He bath at 1.20 K is ~43 hours
 - On orbit expect ~1.10 K and 38 hour hold time
- Heat load is 0.87 μW
 - Measured 84% heat absorption efficiency



Heat loads to 50 mK

Heat switch:	0.015 μW
Detector assy:	0.27 μW
Kevlar susp:	0.58 μW




2-Stage ADR Recycling

- Recycle time <1 hour, including recovery time
 - Detector response stabilizes as detector and ADR components equilibrate
- Control setpoints are based on the He tank temperature (uses mounting plate T)
 - Control system automatically adjusts to conditions during flight



Temperature Stability

- Required stability: 2.5 μK rms
- Actual: 0.37 μK rms




2-Stage ADR Operation Summary

- Recycle time, including detector equilibration: ~1 hour
- Hold time: 43 hours
- Instrument observing efficiency (duty cycle): >97%
- Temperature stability <1 μ K rms

- Integrated heat flow to helium tank
 - Hysteresis from S1 and S2 magnets 3.42 J
 - HS1/HS2 getter power 0.76 J
 - Heat from salt pills 7.84 J
 - Total 12.02 J
- Time average load to He tank is 0.077 mW
 - Requirement is <0.2 mW
 - If ADR is recycled every day, heat per cycle is ~10 J, avg is 0.115 mW


Cryogen-Free Operation

- 3rd stage transfers heat to JT cooler
- 2nd stage maintains helium tank temperature (goal <1.5 K)
 - Builds up cooling capacity during hold time
- 1st stage cools detectors to 50 mK, rejects heat to 2nd stage




3rd Stage Cycling

- Cycle period ~21 minutes
- Low temperature setpoint is continuously adjusted to match helium tank T
- Time average heat lift of 2-3 mW in range of 1.4-1.8 K
 - Helium tank parasitic load is ~0.6 mW
 - ADR internal heat generation is ~1.2 mW




Full Cycle with He tank at 1.625 K

- S2 charges during S1 hold time
- S1 is automatically recycled when current falls below 20 mA
- 40 minute recycle
- 11.0 hour hold
- >94% observing efficiency



He Tank Control



- Lower He tank temperature = slower charging rate of Stage 2



- On orbit, tank will be regulated at lowest temperature at which Stage 2 charges completely during Stage 1 hold time
 - 1.5-1.55 K, based on current test conditions
 - Will change if cryocooler performance degrades over time


Stage 1 Cycling

- Stage 1 automatically recycles at 10 mA current




Detector Housing Temperature Stability

- Required stability is 1 mK over time scales of 0.2 s – 10 min
 - Brief periods in which fluctuation is ~2 mK
 - With current detector performance, this is acceptable



Heat Flow to the JT Cooler


- Cycling was adjusted to give max heat flow of 30 mW
 - Maximum flow tolerable at nominal input power



Warm Start

- ADR must handle the case of a warm start
 - He tank, ADR and detectors starting at 4.5 K
 - May be necessary after catastrophic warmup
 - Due to loss of cryocooler operation for long period
 - Due to issues with guard vacuum
- Control must be autonomous
 - No intervention via ground control

Cooldown from 4.5 K



Summary

- ADR operates successfully with 2 very different heat sinks
- Demonstrated autonomous control in all operating modes
 - 2-stage with helium
 - 3-stage in cryogen-free mode
 - Warm start, automatic recycling
 - Pre-launch (maintain He temperature during launch hold)
- Meets all instrument requirements
 - Cooling power
 - Temperature stability
 - Instrument observing efficiency
 - Heat rejection to He bath or JT cryocooler